


# OPERATOR'S MANUAL

## HAYLINER

### 376

SPERRY  NEW HOLLAND



# CONTENTS

	PAGE
<b>INTRODUCTION</b>	1
<b>WARRANTY</b>	2
<b>SAFETY</b>	3
<b>SPECIFICATIONS</b>	4
<b>LUBRICATION</b>	5
<b>ATTACHING THE BALER TO THE TRACTOR – 3 joint P.T.O. shaft</b>	8
<b>– 2 joint P.T.O. shaft</b>	9
<b>THREADING THE BALER</b>	10
<b>MOVING THE DRAWBAR TO TRANSPORT POSITION</b>	11
<b>MOVING THE DRAWBAR TO WORKING POSITION</b>	12
<b>PARKING THE BALER</b>	12
<b>WINDROW PREPARATION</b>	13
<b>PLUNGER SPEED</b>	13
<b>STARTING TO BALE</b>	14
<b>BALE LENGTH ADJUSTMENT</b>	15
<b>BALE SHAPE ADJUSTMENT</b>	16
<b>BALE WEIGHT ADJUSTMENT</b>	16
<b>REPLACING FLYWHEEL SHEAR BOLT</b>	17
<b>REPLACEMENT OF THE KNOTTER DRIVE SHEAR BOLT</b>	18
<b>BALER ADJUSTMENTS</b>	19
P.T.O. drive slip clutch	19
Needle safety latch	20
Pick-up drive slip clutch	21
Pick-up over-run clutch	21
Pick-up windguard	21
Pick-up wheel	21
Bale counter	21
Knotter trip arm in reset position	22
Tripping the knotter	22
Wheel lock cable	22
Tine bar bearings	23
Tine bar removal	24
Pick-up lift spring	24
Trip arm adjustment	25
Feeder drive chain	25
Tine bar timing	26
Feeder crank arm timing	27
Needle timing	27
Plunger knife clearance	28
Adjusting plunger and stationary knives parallel	30
Plunger guide adjustment	30
Vertical plunger adjustment	31
Adjusting the knotter pawl stop	32
Adjusting the knotter brake	32
Knotter stack end play	33
Knotter mounting bolts	33
Twine disc timing	34
Twine holder spring	34
Bill hook cam	35
Knife arm	35
Adjusting needles and needle penetration	36
Adjusting twine fingers	38
<b>BALER SERVICE CHART</b>	39
<b>KNOTTER SERVICE CHART</b>	43

# LUBRICATION

The SPERRY NEW HOLLAND Super Hayliner 376 is designed to require a minimum of lubrication. However, regular lubrication is the best insurance against delay and repairs and greatly increases the life of the machine. Under normal conditions, the baler should be lubricated after every 3,000 bales of operation.

Following is a list of the points that require lubrication with a reference number that identifies each point on the corresponding figures.

All points except those with special notations should be lubricated until grease is forced out around the bearings and then the excess grease should be wiped off.




Figure 1

1. Fig. 1 – Universal joints (3 off).
  2. Fig. 1 – Telescoping shafts (2 off).
  3. Fig. 1 – Flywheel bush.
  4. Fig. 1 – Gearbox shaft.  
Do not force grease only until slight pressure can be detected.
  5. Fig. 1 – Needle safety latch.  
Oil linkage as required.
  6. Fig. 1 – Connecting rod.  
Lubricate every 10,000 bales.
  7. Fig. 1 – Jack.
  8. Fig. 1 – Over-run clutch pins.  
Oil sparingly with light oil.
  9. Fig. 1 – Gearbox.  
Check oil level every 6,000 bales.  
Fill to level plug with good grade hypoid lubricant SAE 90.
- IMPORTANT :** Failure to grease this could result in needle breakage.

## STARTING TO BALE

1. Lower pick-up and ensure overcentre latch A (Fig. 17) is pointing forward.
2. Adjust pick-up wheel height B to suit crop conditions.
3. Swing drawbar to working position C (Fig. 17).
4. Ensure jack is in its raised position D (Fig. 17).
5. Ensure P.T.O. support is folded back, E (Fig. 17).




Figure 17

6. Lower bale chute F (Fig. 18).
7. Adjust bale tension cranks G (Fig. 18) so that approximately 150 mm (6") of thread is exposed.
8. Adjust tractor throttle to obtain 540 P.T.O. speed.
9. Select a gear which gives approximately 4 km/h (2.5 MPH) at the same throttle setting.
10. Move forward into the swath and bale 10 – 12 bales.
11. Stop tractor and check bale weight.  
If necessary, adjust bale tension cranks to achieve the required bale weight.




Figure 18

### IMPORTANT :

If knotters have not tied the bales correctly, **do not make any adjustment at this time**, but ensure that the baler is correctly threaded and that no twine is hanging on the bill hook, then continue baling and observe the result.

**DO NOT ATTEMPT TO CHECK KNOTTER  
OR MAKE ADJUSTMENTS WITH TRAC-  
TOR ENGINE RUNNING.**